

# PW1 RÉPÉTITION MINUTES - Argentium®

25-piece Limited Edition

## Technical Notes

This grand complication is characterized by an exceptional movement and the innovative alloy of its Argentium® case. A symbol of Bell & Ross's expertise, the PW1 Répétition Minutes marks time like the clocks of the past: the hour is not read but heard. A timepiece with a complicated mechanism that indicates, on request, the hours and minutes musically.

### GENERAL DESCRIPTION

**Movement** Mechanical with manual winding. 18,000 beats per hour. Power reserve of about 45 hours. High-precision adjustment. **Functions:** hours (B), minutes (A), small second hand (C). Five-minute repeater (D): striking mechanism using gongs: one gong for the hour, two gongs for five minutes. **Case** in Argentium®: 52 mm in diameter and 17 mm thick. **Glass:** anti-reflective sapphire. Sapphire case back with protective lid. Silver chain.

*Argentium 960®: purer than traditional silver, this alloy is more striking and more resistant to oxidation.*

### GENERAL USAGE


**Winding.** When the watch has stopped (crown in position 0): wind the mechanism by turning the crown clockwise. After approximately 25 rotations, the watch will be fully wound. The operating time is then about 45 hours. **Setting the time.** Pull the crown into position 1. Set the time by turning the crown in the desired direction.

### ACTIVATING THE STRIKING MECHANISM (five-minute repeater)

The striking mechanism is activated by pressing the button (D) on the left-hand side of the case. A low-pitched gong sounds the hours. A double gong sounds after periods of five minutes.

### MAINTENANCE

When traces of oxidation appear on the case, simply use the cloth supplied with your watch. Imbued with a specific cleaning product, it will restore sparkle to the Argentium®. In order to guarantee service compliant with the requirements of the brand, any servicing on your watch must be carried out by a Bell & Ross repair center or a watchmaker approved by Bell & Ross. For any repairs under warranty, you will need to present the Bell & Ross warranty card, duly dated and signed by the retailer at the time of purchase.



- A. Minute hand
- B. Hour hand
- C. Small second hand
- D. Button to activate striking mechanism
- E. Crown
- F. Button to open lid

1. Wind the mechanism manually (clockwise).  
Please note: do not force it lest you damage the mechanism
2. Set the time (either clockwise or counterclockwise)

### THE BELL & ROSS INTERNATIONAL GUARANTEE

Your Bell & Ross watch has successfully passed the most rigorous reliability tests in the Swiss watch-making industry. It is guaranteed against all manufacturing defects for 2 years from the date of purchase entered by the Bell & Ross approved retailer on the international guarantee certificate subject to applicable laws and/or legal guarantees. This guarantee is total (parts and labor). It excludes however:

- . Damage that is the result of accidents or improper or incorrect use of the watch (violent shock, crushing, brutal handling of the clasp).
- . Damage that is the result of repairs or dismantling not carried out by an approved Bell & Ross retailer or an approved after-sales service center.
- . The results of normal use and wear of the watch and strap. This also excludes batteries given the specific nature of these items.

**IMPORTANT :** To be covered by the Bell & Ross International Guarantee, any work must be carried out by approved specialists : retailers approved by Bell & Ross, approved after-sales service centers. This guarantee can only be applied on presentation of the Bell & Ross International Guarantee certificate, duly completed, dated and signed by an approved retailer.

Models and Technical features subject to change